

E 190Q – Autonomous Robot Navigation

Jaguar Lite

Software Install Instructions

1. Download the **Jaguar_BaseCode** folder to the Desktop from the course web site.
2. Go to the **DVD RW Drive JaguarLite_Laser > JaguarControlSetup**
Run **setup.exe** (Select Next, install Dr Robot Jaguar Control for *Everyone*, etc.)
3. Go to **DVD RW Drive JaguarLite_Laser > Microsoft DirectX SDK**
Open the **directx_mar2008_redist** application (Select Yes for the agreement)
4. Create a subfolder in **C:\Program Files (x86)\Dr Robot Inc** called **Jaguar_DirectX**
Set it as the destination for extracted files and press OK.
5. Look in the Jaguar_DirectX folder and run the **DXSETUP** application.
(Accept the agreement, select Next x2)
6. Download Google Earth online - <http://www.google.com/earth/download/ge/>
7. Go to **DVD RW Drive JaguarLite_Laser > AxisCamera**
Run the **AXISMediaControlSDK** application (Select Next, accept, Next).